



Universität Hamburg

DER FORSCHUNG | DER LEHRE | DER BILDUNG

MIN Faculty
Department of Informatics



Tactile based grasping with the biomimetic sensors BioTac and the Shadow Dexterous Hand

Yannick Jonetzko



University of Hamburg
Faculty of Mathematics, Informatics and Natural Sciences
Department of Informatics
Technical Aspects of Multimodal Systems

12. December 2017



Outline

Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept

1. Review of last talk
2. Shadow Hand
3. BioTac
 - Sensor data
 - Preprocessing
 - Contact
4. Tactile grasping - Proof of Concept





Review of last talk

Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept

1. Introduction
2. Shadow Hand
3. BioTac
 - Raw Data
 - Filter
 - Normalization
 - Point of contact
 - Calibration*
4. *Stable grasp*
 - Controller*
5. *Integration with the PR2*



Shadow Hand

Review of last talk

Shadow Hand

BioTac


Tactile grasping - Proof of Concept



Shadow Dextrous Hand¹


¹<https://www.shadowrobot.com/>

Shadow Hand - Kinematics



Shadow Dexterous Hand kinematics ²

²http://www.shadowrobot.com/wp-content/uploads/shadow_dexterous_hand_technical_specification_E1_20130101.pdf



BioTac cross section³

³https://www.syntouchinc.com/wp-content/uploads/2017/01/BioTac_Product_Manual.pdf

- ▶ Electrode voltages (E1 - E19) - Measure voltage
- ▶ DC Pressure (Pdc) - Absolute fluid pressure
- ▶ AC Pressure (Pac) - Dynamic fluid pressure (vibrations)
- ▶ DC Temperature (Tdc) - Device temperature
- ▶ AC Temperature (Tac) - Thermal flux

All incoming values from 0 to 4095


Electrode Voltages (E1 - E19) - Impedance

Review of last talk

Shadow Hand


BioTac

Tactile grasping - Proof of Concept



Top: raw data; Bottom: filtered and normalized

DC Pressure (Pdc)




Top: raw data; Bottom: filtered and normalized

Goal

Get information which are useful for grasping.

E.g.: Point of contact, contact force

To calculate these informations the data is preprocessed:



Preprocessing



Temperature Compensation

Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept




Preprocessing

Temperature Compensation

$$\text{temp_}e'_i = e_i - \text{tdc} \cdot \alpha_i$$

With:

- ▶ e_i : Raw electrode value
- ▶ tdc : Raw temperature value
- ▶ α_i : Compensation constant



α values for first finger



Preprocessing Filter

Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept

Noise filtering with the Exponentially Weighted Moving Average (EMA)

$$EMA_n = \alpha \cdot x_n + (1 - \alpha) \cdot EMA_{n-1}$$


With:

- ▶ α : From 0 to 1
- ▶ $EMA_0 = 0$
- ▶ x_n : New value

Preprocessing normalization

Idea

Pdc, pac and electrode values should be 0 in an idle state



Normalization state diagram



Most important properties of a contact:

- ▶ Point of contact
- ▶ Normal force

Other properties which will not be regarded:

- ▶ Contact Area
- ▶ Tangential forces
- ▶ ...



Contact

Point of contact


Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept

Video





Contact Ground truth

Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept




Ground truth setup

Contact

Point of contact

Idea:

1. Get the average of the electrode position, weighted with the impedance value
→ position on the core of the BioTac
2. Map position to surface and distinguish between:
 - ▶ Cylindrical part
 - ▶ Spherical part



BioTac origin ⁴

⁴https://www.syntouchinc.com/wp-content/uploads/2016/12/2013_Lin_Analytical-1.pdf



Contact

Point of contact

Compute the PoC by a weighted average of the position of the electrodes:

$$\langle x_c, y_c, z_c \rangle = \frac{\sum_{i=1}^{19} (|e_{i*}|^n \langle x_i, y_i, z_i \rangle)}{\sum_{i=1}^{19} (|e_{i*}|^n)}$$

e_{i*} : Normalized electrode values

n : Impact of the single electrode





Point of contact

Improved analytical approach

Considering only negative electrode values

$$\langle x_c, y_c, z_c \rangle = \frac{\sum_{i=1}^{19} (|e_{i^*}|^n \langle x_i, y_i, z_i \rangle)}{\sum_{i=1}^{19} (|e_{i^*}|^n)} \quad \text{with} \quad e_{i^*} = \begin{cases} e_i & \text{for } e_i < 0 \\ 0 & \text{for } e_i > 0 \end{cases}$$


Point of contact Evaluation

Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept



Point of contact Evaluation

Review of last talk



Shadow Hand

BioTac

Tactile grasping - Proof of Concept

Average error:

- ▶ Original: 3.42 mm
- ▶ Improved: 2.01 mm



Distance error distribution



Point of contact

Calibration of electrodes

Goal

Improve point of contact accuracy by calibrating the electrode values

Problem: Electrodes react differently to the same amount of force

Calibration approaches:



1. Generate transfer function for each electrode with ground truth force
2. Normalize electrode values between -1 and 1 with minimum and maximum



Point of contact

Calibration of electrodes

Transfer functions for electrode 3 and electrode 14



Point of contact

Calibration of electrodes

Review of last talk

Shadow Hand


BioTac

Tactile grasping - Proof of Concept

$$e_{i_norm} = \frac{e_i^*}{e_{i_min}^*}$$

With:

- ▶ e_i^* : Preprocessed electrode value
- ▶ $e_{i_min}^*$: Minimum value at electrode i




Minimum values



Point of contact Evaluation

Average error:

- ▶ Ground truth force: 2.44 mm
- ▶ -1 to 1 normalization: 2.04 mm




Distance error distribution

Idea

Generate transfer function between pdc and force

Problem: Relation between force and pdc depends on contact point




Normal force estimation

Transfer functions

Generate 19 transfer functions at electrode positions and interpolate between them with distance-based interpolation

$$F_N = \begin{cases} \frac{\sum_{i=1}^3 \frac{1}{d_i} \cdot \text{trans}_i(P_{DC})}{\sum_{i=1}^3 \frac{1}{d_i}} & \text{for } d_1 > 0 \\ \text{trans}_i(P_{DC}) & \text{for } d_1 = 0 \end{cases}$$





Normal force estimation

Evaluation


Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept

Accuracy of 0.356 N with estimated contact point






Idea

Include tactile feedback in grasping motions

Grasping process:

1. Move both finger to requested position
2. Stop motion of finger on contact
3. Apply requested force when both fingers have a contact



Tactile grasping - Proof of Concept

Review of last talk

Shadow Hand

BioTac

Tactile grasping - Proof of Concept



1. Closing



2. First contact



3. Second contact: Apply force


Tactile grasping - Proof of Concept

Review of last talk

Shadow Hand


BioTac

Tactile grasping - Proof of Concept





- ▶ Successful grasping an object
- ▶ BioTac data is preprocessed and can be used
- ▶ Contact point and normal force are estimated for contacts
- ▶ Calibration could be improved to increase accuracy





- ▶ Try to learn point of contact and normal force
- ▶ Extend controller for more finger
- ▶ Integrate grasping with the PR2
- ▶ Use preprocessed BioTac data to read braille
- ▶ ...

